















NOVA PRO SCALA - Ladegeleiding handleiding

ADJUSTMENT

Height adjustment			
	<div>1</div> 	<div>2</div> 	<div>3</div> 
Side adjustment			
	<div>1</div> 	<div>2</div> 	<div>3</div> 
Tilt angle adjustment H90 with rectangular railing		Tilt angle adjustment H90 with rectangular railing and front support	
	<div>1</div> 		<div>1</div> 
Tilt angle adjustment H122, H186, Crystal and Crystal Plus			
	<div>1</div> 		

ASSEMBLY/REMOVAL

Inserting		Removal	
